


LOCKDOWN IN-FLOOR SAFES



FOR THE
**SECURITY
CONSCIOUS**



↑ DUST COVER ↑

BODY: Reinforced with slam bars for added security.

DOOR: Spring assisted door pivot. Removable doors interchange.

MOUNTING: Suitable for installation in concrete or concrete encased in timber floors with heavy duty lid (dust cover) forming part of floor surface.

RELOCKING DEVICE: Emergency relocking device incorporated in door.

BOLTWORK: Flip bolt locking mechanism.

INSURANCE: Suggested insurable cash rating for Lockdown In-floor Safe in an unsupported (no alarms) domestic situation is **\$20,000**.

LOCKING OPTIONS:

- Digital locking
- Dial combination locking
- Key locking

	HEIGHT	WIDTH	DEPTH	WEIGHT
EXTERNAL	390mm	370mm	350mm	26kg
INTERNAL	260mm	295mm	270mm	

MODEL LCD-D	\$	INCL. GST
-----------------------	----	-----------


MODEL LCD-C	\$	INCL. GST
-----------------------	----	-----------

MODEL LCD-K	\$	INCL. GST
-----------------------	----	-----------

DELIVERY & INSTALLATION LEVEL ACCESS METRO	\$	INCL. GST
--	----	-----------

SYDNEY AUSTRALIA

Installation into existing concrete floor




IF INSTALLING INTO A PROPOSED SITE, ALLOW 600mm FORMED CUBE WHEN POURING FLOOR TO ACCEPT FLOORSAFE, WHEN HOUSE IS UP TO LOCKUP STAGE, THEN INSTALL IN CONCRETE IN IMMEDIATE AREA.



IMPORTANT
FLOOR SAFES ARE
NOT WATER PROOF.

Installation into timber floor



DOOR MUST BE OPEN FOR 48 HOURS WHILE CONCRETE SETS

IN DAMP SITUATIONS THE
CONCRETE (1 X SAND
+ 1 X 10mm STONE
+ 1 X CEMENT SHOULD
CONTAIN A WATERPROOFING
AGENT SUCH AS "SILASEC"
OR "YURITE" (AVAILABLE
FROM HARDWARE STORES).

ATTENTION INSTALLER/CUSTOMER BEFORE INSTALLING THIS SAFE. Please read these recommendations and instructions.

1. The floor opening should be at least 500mm square.
2. The safe should be secured with a strong mix concrete of at least 40 megapascals (6000 P.S.I.)
3. Steel reinforcing concrete material can also be used to help bond the concrete and provide better security.
5. Topping can be brought up to floor level, but allow about 3mm for the lid to fit on to the frame of the safe and finish flush with floor.
6. Check site for dampness, you may need to add a chemical waterproofing agent to the concrete to avoid dampness within the safe.
7. Check site prior to preparation of installing that there is no interference with cables or pipes.
8. Try to avoid sites that may allow water across the floor and into the safe such as laundries, bathroom areas, garages etc.
9. A minimum of 100mm overall concrete around and under the safe is preferred.
10. During the installation **DO NOT ALLOW** concrete or water to come in contact with the lock, especially electronic locks, this may cause the lock to fail at a later date.
11. **AFTER** installing the safe, dry any moisture from within the safe and allow the safe to dry for **48 hours**.
12. **During the 48 hour drying period, you must leave the door open to avoid any type of condensation reaction and ensure a successful installation.**
13. Clean the interior and top of the safe of any grit or sand prior to closing the door, this will ensure the door operates and locks correctly.

Note: If an infloor safe is left for extended periods without use, lack of air circulation can result in a musty environment for the items stored within.

Check the lock is operating BEFORE closing and locking the door into place.



ALL CMI SAFES COME WITH A FIVE YEAR WARRANTY, EXCLUDING FREIGHT AND TRAVELLING, WITH A 24 MONTH WARRANTY ON LOCKS.

Supplied & Expertly installed by:



1300 764 971
www.safeguardsafes.com.au

Designed by CMI Safe Co. & manufactured in China to CMI specifications, this product is supplied with the same quality assurance & 5 year warranty on construction synonymous with CMI locally manufactured products. Digital & mechanical combination UL rated lock or Australian made ROSS keylocks with a 2 year warranty are fitted in CMI Sydney factory during a rigid pre-delivery inspection. Fully supported by the CMI Safe Co. commitment to customer service, available nationally.